

SOMPRODUCT



Instructiuni de Asamblare pentru **H690**

KRZESLO H690

	 ① × 1	 ③ × 2 M6*20	 ⑤ × 4 ø16*ø6
	 ② × 1	 ④ × 2 M6*12	 ⑥ × 1 4#

The main assembly diagram illustrates the connection of the backrest frame (1) to the seat (2). It shows the backrest frame being positioned behind the seat. Two screws (3) are used to secure the backrest frame to the seat's rear edge. Two additional screws (4) are used to secure the backrest frame to the seat's side rails. Washers (5) are placed between the backrest frame and the seat to ensure proper fit. Brackets (6) are used to reinforce the connection points. The final view of the assembled chair is shown at the bottom left, with an arrow pointing to the assembly diagram.

În cazul în care întâmpinați
dificultăți în asamblarea
produsului, vă stăm la
dispoziție.

Contact:



0316 300 830



clienti@somproduct.ro

SOMPRODUCT

